



Fig. 1a






- Key:
- | | |
|---|-----------------------|
| 1 | Steering wheel |
| 2 | Steering column shaft |
| 3 | Cone |
| 4 | Nut |
| 5 | Hollow shaft |

- 6 Steering column housing
- 7 Bearing
- 8 Bearing
- 9 Bearing
- 10 Gear rim
- 11 Gear rim
- 12 Airbag
- 13 Hollow shaft
- 14 Cone
- 15 Cone
- 16 Nut
- 17 Sliding bushing
- 18 Sliding bushing
- 19 Cable


Fig. 1c












- Key: 2 Steering column shaft
 6 Steering column housing
 10 Gear rim
 11 Gear rim
 13 Hollow shaft
 19 Cable





Key: 20 Intermediate gear





*Fig. 4a**Fig. 5a*



Key: 21 Lower pinion gear
22 Rack










- Key: 1 Steering wheel
 6 Steering column housing
 12 Airbag

19	Cable
23	Molded tube
24	Molded bearing part
25	Screw
26	Upper steering column shaft
27	Lower steering column shaft
28	Bearing
29	Sun gear
30	Sun gear
31	Axle
32	Planet gear
33	Planet gear
34	Plug connector











Key: 1 Steering wheel


6	Steering column housing
12	Airbag
19	Cable
23	Molded tube
24	Molded bearing part
26	Upper steering column shaft
27	Lower steering column shaft
28	Bearing
29	Sun gear
32	Planet gear
34	Plug connector










- Key:
- | | |
|--------|-------------------------|
| 6 | Steering column housing |
| 19 | Cable |
| 23 | Molded tube |
| 26, 27 | Steering column |
| 29, 30 | Sun gear |
| 32, 33 | Planet gear |



- Key:
- | | |
|----|---------------------|
| 19 | Cable |
| 24 | Molded bearing part |

25	Screws
34	Plug connector











Fig. 10b

Key: 35 Gearwheel

- 36 Gearwheel
- 37 Gearwheel
- 38 Welded sheet metal construction


*Fig. 10c*






Key: 34 Plug connector

35	Gearwheel
36	Gearwheel
37	Gearwheel
39	Gearwheel
40	Support
41	Stamped sheet metal housing



*Fig. 12.a*





Fig. 12b

Key: 43 Transmission
 44 Gearwheel

45	Gearwheel
46	Gearwheel
47	Gearwheel
48	Gear axis
49	Housing






Fig. 13a




Fig. 13b

Key: 50 Servo mechanism/Power steering system
51 Shaft end







Fig. 13a







Key: 26 Upper steering column shaft


27	Lower steering column shaft
52	Gear
53	Device for changing transmission
54	Computer
55	Speed
56	Angle of rotation
57	Transmission ratio









Key:	12	Airbag
	19	Cable
	60	Tube
	61	Spring
	62	Contacts









- Key:
- | | |
|----|-----------------------------|
| 1 | Steering wheel |
| 12 | Airbag |
| 19 | Cable |
| 63 | Short steering column shaft |
| 64 | Long steering column shaft |
| 65 | Cover |


66	Chain wheel 1
67	Chain wheel 2
68	Setscrews
69	Housing 1
70	Sheet metal enclosure
71	Chain
72	Stationary tube
73	Housing 2





Section "D"

Fig. 17a





Section "D"


Fig. 17b

Key:	63	Short steering column shaft
	64	Long steering column shaft
	67	Chain wheel 2
	68	Setscrews
	69	Housing 1
	70	Sheet metal enclosure
	71	Chain
	72	Stationary tube

73 Housing 2







Key: 1 Steering wheel

12	Airbag
19	Cable
74	Stationary steering column tube
75	Gearing
76	Gearwheel
77	Shaft
78	Gearwheel
79	Gearwheel
80	Steering column shaft







Fig. 18d




Section E Fig. 19a




Key:	1	Steering wheel
	19	Cable
	74	Stationary steering column tube
	76	Gearwheel
	77	Shaft
	78	Gearwheel
	79	Gearwheel



Section E Fig. 19a





Key:	1	Steering wheel
	19	Cable
	74	Stationary steering column tube

75	Gearing
76	Gearwheel
77	Shaft
78	Gearwheel
79	Gearwheel
80	Steering column shaft

